



Bottoming Holes May
Need Shorter Bolts 8mm X 20mm
Check and Make Sure
The 8mm X 25mm Bolts
Will Go In Deep Enough

Ford 5R110 & 5R110W