

## **F 14-300 Sway Bar Spacer**

**F-450 1 needed**

**F-550 2 needed**

No spacer needed for F-350.

For the F-450, a spacer is required on the passenger side mounting bracket. Remove bolts on passenger bracket. Install spacer with longer bolts included. Tighten bolts 25-30 Ft lbs.



For the F-550, spacers are required on both side mounts. When reinstalling sway bar include the spacers on each side using the bolts supplied with spacer kits. Tighten bolts 25-30 Ft lbs.

